




SAVE  
££.PP



Top frame




Mid frame



Back frame lower half (internal)




Money box front panel




External graphics












← Money box Inner panel cover



Outer upper frame overlays




Top frame





Mid frame

The diagram shows a stepped shaft with a central section labeled "Mid frame". The shaft has a central section with a diameter that is larger than the sections on either side. The central section is shaded with diagonal lines. The shaft is shown in a perspective view, with the central section being the largest and the end sections being smaller. The text "Mid frame" is centered on the largest section of the shaft.

Back frame upper half





Back frame lower half

Money box front panel

Money box  
inner panel

The diagram shows a money box assembly. At the top, there are two side panels, each labeled "Money box side panel". Below these is a large top panel labeled "Money box top panel". At the bottom is a large bottom panel labeled "Money box bottom panel". A small rectangular piece is shown protruding from the bottom edge of the top panel, and another small rectangular piece is shown protruding from the top edge of the bottom panel, indicating they fit together.

Money box  
side panel

Money box  
side panel

Money box top panel

Money bottom panel

