



Rev 1.0 Ver 1.0
Explosive
Control Module

Buzzer

Output

26V0

ACC
ZIG

ACC
TRIG
ECHO
BLUE
GREEN
RED
GND

RESET

25
+
27
+